



Authorized Dealer
SUNCOAST
M o t o r s p o r t s

SCREENTECH PRO

- Advanced Optically Clear, Hi-Resolution Film
- Invisible Protection, Scratch-Resist Surface
- Anti-Fingerprint, Oleophobic Coating
- Touch & Navigate Friendly, Low Friction Surface
- Anti-Shock, Non-Shattering Nanotech Polyglass
- Apply Dry - Electronics & Touchscreen Safe
- Fast, Easy, Bubble-Free Installation
- Non-Permanent, No Residue, Removable Film

HOW TO INSTALL

1. Clean factory screen thoroughly, removing any debris
2. Peel off black liner from the back of the film,
avoid touching the exposed adhesive lining
3. Carefully, place the film directly over the factory screen
4. Gently press at the center allowing adhesive to spread out
5. Use the provided squeegee, work from the center out
any remaining air pockets trapped beneath the film
6. Upon careful inspection, remove the blue liner from the front
of the film to complete